

Terminals explanation
Read the manual

1 - Push button A
2 - Remote On/Off
3,4 - VE.Bus
5 - Current Sense
6 - a,b (+,-) K1
c,d (+,-) Ext. GND
e,f (+,-) Aux2
g,h (+,-) Aux1
7 - a,b (+,-) T-Sense
c,d (+,-) V-Sense
8 - Aux Relay

K (V-sense)

B (T-sense)

F

G

G

J

O

L

M

N L2 PE L1

AC-OUT 1

AC-OUT 2

N L2 PE L1

AC-IN

N L2 PE L1

AC-OUT 1

AC-OUT 2